

# Self Pump Out Kit Operation Guidelines





Electric Self P/O Kit Part No: (12v) 02770 (24v) 02771 Light Duty Self P/O Kit Part No: 01019 Heavy Duty Self P/O Kit Part No: 01340

















Wharf Road, Fenny Compton, Warwickshire CV47 2FE

**Sales:** +44 (0) 1295 770000 **Support:** +44 (0) 871 288 5726 **Fax:** +44 (0) 1295 770022

E: sales@leesan.com www.leesan.com



## Self Pump Out Kit Operation Guidelines

For the purpose of these operation guidelines, we will use the light duty self pump out kit, the principles of use are the same for all three units

## Unpack Your Self Pump Out Kit



Lay the hose out to the Elsan disposal point and make the connection to the pump



Rinse the pump and pipework with Raw water to check the connection and pump



Open the Deck fitting on the boat and connect the suction pipe





















### Self Pump Out Kit Operation Guidelines

## Start operating the pump



Once you notice a change in the sight glass, add some rinse water to the tank and pump the tank empty again



Having emptied the tank, disconnect the pipe from the deck fitting and rinse the unit through with pumping raw water



Pack the unit neatly away and return the kit to the locker until you need it again























## Self Pump Out Kit Related Products

#### **Service Kits**



Light Duty, Part No: 01025 Heavy Duty, Part No: 01400 Low Voltage Electic, Part No: 02799



Single Ply Loo Roll (Pack of 4)

## **Toilet Cleaning**



LeeScale



**Toilet Bowl Cleaner** 



LeeGuard



Clean & Green (12 Sachets)

#### More products to be found at www.leesan.com















