


Inspection Hatch Cover

Top Plate

O Ring

Bottom Plate



Dimensions in millimetres

LeeSan Part No: 01585

1. Cut 115mm hole in the tank
2. Push nylon spike into the hole in the underside of the top plate
3. Loosely screw the top plate to the bottom plate with stainless bolt
4. Rotate bottom plate through the hole into the tank and tighten screw with o-ring on the top tank surface

For a short video on how to install the Inspection hatch